

Forestersubaruspare

Foresters servicing schedule:2010-2011

R=Replace I=Inspect

Service Item	1000 mile	7500 mile	15000 mile	22500 mile	30000 mile	37500 mile	45000 mile	52500 mile	60000 mile	see note
Sump seal	R	R	R	R	R	R	R	R	R	
Drive belts (except camshaft)	I	I	I	I	I	I	I	I	I	
Camshaft belts £108							R			
Engine oil £32	R	R	R	R	R	R	R	R	R	1
Engine oil filter £10	R	R	R	R	R	R	R	R	R	1
Engine coolant £8					R				R	
Cooling systems, hoses & connections	I		I		I		I		I	
Fuel filter £27.43					R				R	
Fuel system, line & connections			I		I		I		I	2
Air filter £32			I		R		I		R	1
Spark plugs £42.84			R		R		R		R	
4-Gas Analysis Check			I		I		I		I	
transmission & diff. Gear oil £29.30			I		R		I		R	1
Brake fluid £12	I	I	I	I	R	I	I	I	R	3
Brake pads & discs		I	I	I	I	I	I	I	I	
Axle shafts joints & boots			I		I		I		I	2
Brake lines		I	I	I	I	I	I	I	I	
Park & service brake operation		I	I	I	I	I	I	I	I	2
Clutch system	I		I		I		I		I	
Full geometry check	Perform as required at additional cost									
Steering & suspension system			I		I		I		I	2
Operation of lights, wipers, washers	I	I	I	I	I	I	I	I	I	
Tyre condition and inflation pressures	I	I	I	I	I	I	I	I	I	
Wheel bearing lubricant									(I)	
TOTAL COST:	£88.84	£88.84	£163.02	£88.84	£351.67	£88.84	£331.02	£88.84	£351.67	

All prices include 20% VAT and labour charges

Also available with all above services at £25.40 as recommended by the Good Garage Scheme

Oil flush and fuel system treatment

Saves money on fuel bills and reduces emissions

Removes sludge and lacquer build-up from the engine internals

Restores lost performance

Cleans the entire fuel and exhaust system, from tank to tail pipe

Notes:

- 1. If the vehicle is used under severe driving conditions, replace more often than the usual recommended intervals.**
- 2. If the vehicle is used under severe driving conditions, inspect 7,500 miles or 6 months whichever occurs first.**
- 3. If the vehicle is used under high humidity conditions or mountainous areas, replace fluid every 15,000 miles or 12 months whichever occurs first.**

Severe driving conditions are:

- * Driving in extremely cold weather**
- * Towing a trailer**
- * Driving regular short distances**
- * Driving on dusty roads**
- * Driving on rough or muddy roads**
- * Driving in areas using road salt or other corrosive materials**
- * Driving in coastal area**